



QUANTITIES	ACCESSORY
8 Pcs	30*8MM
2 Pcs	
2 Pcs	30*8MM
6 Pcs	40*5MM
1 Pcs	
2 Pcs	black cotton pad diameter 28MM
2 Pcs	Height 22CM
4 Pcs	X2 X2 Leg Installed

STEPS	PLEASE REFER TO THE PICTURES FOR SPECIAL OPERATIONS
①	Install Type C angle irons on the headboard, side rails and footrest, and then paste Type X.
②	Use Type A flat brackets to connect the headboard and side rails.
③	Use Type A flat brackets to connect the side rails and foot rest.
④	Install the stand Y to the folding slat. The stand Y can be adjusted according to the slat.

Note: the 32 pcs Type M bolts are not in the hardware kit. They are already pre-installed in the holes of the frame.

